

BELT THROW BAG *Water Rescue*

RESCUE

Multipurpose Water Rescue Solution Designed For Easy Deployment and Retrieval...

The quick release reverse tapered (allowing for rapid packing and slim profile) throwbag holds 60 ft of 7.5 mm Triton Pegasus Rope® which is rated at over 3,300 lb. Rope features two colored and 1 reflective runner for increased operational visibility and nighttime reflectivity.

The adjustable belt features 2 in. quick release strap, 1.5 in. plastic cam buckle, and red toggle ball for easy ID/throwbag release during water rescue work or paddling. Configured with pre-tied Figure 8 knots on both rope ends to maximize working load of rope, this belt throw bag also features a cinch top with 550 Cord, plastic cordloc & hook-and-loop top flap.

Also includes an external gear pouch with moveable MOLLE attachment system located on belt, secured with zipper top closure and loop Velcro® patch for end user custom ID, keeps your recovery hardware at quick reach even when throw bag is deployed.

Features:

- Designed for easy deployment and retrieval for rescuers
- Quick release reverse tapered throw bag for rapid packing of the Triton rope and a slim profile for users
- Two colored rope runners and 1 reflective runner for increased operational visibility and nighttime reflectivity
- 2 in. adjustable belt with quick release strap, 1.5 in. plastic cam buckle, and red toggle ball for easy ID/throwbag release during water rescue work or paddling
- Additional external gear pouch included on belt with moveable MOLLE attachment to keep recovery hardware always within reach
- Configured with pre-tied Figure 8 knots on both rope ends

Dimensions:

- L 11 in. x W 4.5 in. x D 4 in.
- Weight: 2 lb 8 oz



NORTH AMERICAN RESCUE®
www.NARescue.com • 888.689.6277

ORG

